


Lifting clamp

Flexibore® installation accessory



IDEAL FOR

- All Flexibore® hose
- Both crane and vehicle-assisted installation methods
- Installation and retrieval



Scan here to learn more

Lifting clamps are an essential accessory for the safe installation of Flexibore®. Crane-assisted installations are the most common for larger projects and require two **lifting clamps**. Vehicle-assisted installations, or when using a winch, will also need two clamps. Crusader Hose offers a selection of **lifting clamps** to best suit your bore hose installation project.

Types of lifting clamps:

- **Light-duty lifting clamps** are used where the maximum load is limited to 1.2 tonnes.
- **Heavy-duty lifting clamps** are used where the load exceeds 1.2 tonnes to a maximum load of 4 tonnes.
- **Extra heavy-duty lifting clamps** are available up to 10 tonnes.



Lifting clamp for easy and safe Flexibore® installation

TECHNICAL DATA

Lifting clamp	1.2 tonnes	4 tonnes	5 tonnes	10 tonnes
Hose range (ID)	32 mm - 152 mm	32 mm - 152 mm	32 mm - 254 mm	32 mm - 254 mm
	1.25" - 6"	1.25" - 6"	1.25" - 10"	1.25" - 10"
Weight	11 kg	15 kg	34 kg	39 kg
Dimensions	45 x 10 x 17 cm	45 x 10 x 27 cm	63 x 15 x 32 cm	63 x 15 x 35 cm
Part #	ACF013ASB	ACF040ASB	ACF050ASB	ACF100ASB

Crusader Hose Pty Ltd

22 Industry Place, Bayswater VIC 3153 Australia
 e: sales@crusaderhose.com.au p: +61 3 9720 1100

www.crusaderhose.com.au

2208

